



# BOB-22

## DANTE INTERFACES

*Dante/AES67 Digital Audio Interface BOB 2x2*



# USER MANUAL

PRECAUTIONS
WARRANTY & ENVIRONMENT
PACKAGE CONTENTS
DESCRIPTION & FEATURES
INSTALL & CONNECT
START-UP & OPERATION
NETWORK CONFIG. & Dante/AES67 ROUTING
PANEL FUNCTIONS
TECHNICAL DATA

# TABLE OF CONTENTS

<b>1. PRECAUTIONS.....</b>	<b>3</b>
1.1 Important Notice.....	3
1.2 Key Safety Directions.....	4
1.3 Cleaning Directions.....	4
<b>2. WARRANTY &amp; ENVIRONMENT .....</b>	<b>5</b>
<b>3. PACKAGE CONTENTS.....</b>	<b>5</b>
<b>4. DESCRIPTION &amp; FEATURES .....</b>	<b>6</b>
4.1 Main Features.....	6
<b>5. INSTALL &amp; CONNECT.....</b>	<b>7</b>
5.1 Installation.....	7
5.1.1 Half Rack Adapter Assembly .....	7
5.2 Connections.....	8
5.2.1 Audio input connections.....	8
5.2.2 Audio output connections .....	10
5.2.3 Ethernet / Dante/AES67 port .....	10
<b>6. START-UP &amp; OPERATION.....</b>	<b>11</b>
<b>7. NETWORK CONFIGURATION AND DANTE/AES67 ROUTING .....</b>	<b>12</b>
<b>8. PANEL FUNCTIONS .....</b>	<b>14</b>
8.1 Front Panel.....	14
8.2 Rear Panel.....	15
<b>9. TECHNICAL DATA .....</b>	<b>16</b>
9.1 Technical Specifications.....	16
9.2 Mechanical Diagram.....	17



PRECAUTIONS

WARRANTY  
&  
ENVIRONMENT

PACKAGE  
CONTENTS

DESCRIPTION  
&  
FEATURES

INSTALL  
&  
CONNECT

START-UP  
&  
OPERATION

NETWORK CONFIG.  
&  
DANTE/AES67 ROUTING

PANEL  
FUNCTIONS

TECHNICAL  
DATA

## 1. PRECAUTIONS

### 1.1 Important Notice



**WARNING: SHOCK HAZARD - DO NOT OPEN**


**AVIS: RISQUE DE CHOC ÉLECTRIQUE - NE PAS OUVRIR**



The flashing light with an arrowhead symbol inside an equilateral triangle on it is intended to alert the user of the presence of non-insulated “dangerous voltage” within the enclosure, which might be of sufficient magnitude to pose a risk of electric shock to users.



The exclamation mark within an equilateral triangle is intended to alert the user of the requirement for important operating and maintenance (servicing), for which instructions may be found in the literature accompanying the appliance.

**WARNING (If applicable):** Terminals marked with symbol “” may be of sufficient magnitude to pose a risk of electric shock. The external wiring connected to terminals requires installation by a technician, or the use of ready-made leads or cords.

**WARNING:** To prevent fire or shock hazard, do not expose this equipment to rain or humidity.

**WARNING:** A device with Class I manufacturing ought to be connected to a mains socket outlet with a protective earthing connection.



**WARNING:** Ecler products have a long lifetime of more than 10 years. This product must never be discarded as unsorted urban waste, but must be taken to the nearest electrical and electronic waste treatment centre.



PRECAUTIONS

WARRANTY  
&  
ENVIRONMENT

PACKAGE  
CONTENTS

DESCRIPTION  
&  
FEATURES

INSTALL  
&  
CONNECT

START-UP  
&  
OPERATION

NETWORK CONFIG.  
Dante/AES67 ROUTING

PANEL  
FUNCTIONS

TECHNICAL  
DATA

## 1.2 Key Safety Directions

1. Read the following directions.
2. Keep the following directions.
3. Heed all warnings.
4. Follow all directions.
5. Do not use this device in proximity to water.
6. Clean only with a dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other devices (including amplifiers) that may release heat.
9. Do not defeat the safety purpose of the polarized or grounding type plug. A polarized plug has two blades, being one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, contact a qualified electrician for a replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched, particularly at the plugs, convenience receptacles, and at the point of exit from the device.
11. Only use attachments/accessories specified by the manufacturer.
12. Unplug the device during lightening sorts or when unused for long periods of time.
13. Refer all servicing to qualified personnel. Servicing is required when the device has been damaged in any way, such as power supply cord or plug damage, liquid spillage or objects onto the device, the device has been exposed to rain or humidity, does not operate normally, or has been dropped.
14. Disconnecting from mains: When switching off the POWER switch, all the functions and light indicators of the unit will be stopped, but fully disconnecting the device from mains is done by unplugging the power cable from the mains input socket, therefore, it should always remain easily accessible
15. Equipment is connected to a socket-outlet with an earthing connection by means of a power cord.
16. The marking information is located at the bottom / rear of the unit.
17. The device shall not be exposed to dripping or splashing liquids, and no liquid-filled objects, such as a filled up glass, shall be placed on top of the device.

## 1.3 Cleaning Directions



**Clean the unit with a soft, dry clean cloth** or slightly wet with water and neutral liquid soap only, then dry it with a clean cloth. Be careful that water never gets into the unit through any hole. Never use alcohol, benzine, solvents or abrasive substances to clean this unit.

**NEEC AUDIO BARCELONA, S.L.** accepts no liability for any damage that may be caused to people, animal, or objects due to failure to comply with the warnings above.

## 2. WARRANTY & ENVIRONMENT

**Thank you for choosing our Ecler BOB-22!**

**We greatly value your trust.**

It is **VERY IMPORTANT** to carefully read this manual and to fully understand its contents before any connecting takes place in order to make the best use of this equipment, as well as to get the best performance from it.

To ensure optimal operation of this device, **we strongly recommend that its maintenance be carried out by our authorised Technical Services.**

**All ECLER products are covered by warranty**, please refer to [www.ecler.com](http://www.ecler.com) or the warranty card included with this product for the period of validity and conditions.



**Ecler is truly committed with the environment and planet sustainability, energy saving and CO<sub>2</sub> emission reduction.** Recycling materials and using non-contaminant components are also top priorities in our green crusade.

**Ecler has deeply evaluated and analyzed the environmental impacts of all the processes involved in the production of this product, including packaging, and has alleviated, reduced and/or compensated for them.**

## 3. PACKAGE CONTENTS

- 1 x BOB-22
- 4 x Rubber Foot
- 2 x Euroblocks connectors (green colour)
- 2 x Euroblocks connectors (blue colour)
- 1 x Half Rack Front Adapter
- 4 x Washer (use them when mounting the device on a front rack to prevent marks on the device side brackets).
- First Steps Guide
- Warranty card



PRECAUTIONS

WARRANTY & ENVIRONMENT

PACKAGE CONTENTS

DESCRIPTION & FEATURES

INSTALL & CONNECT

START-UP & OPERATION

NETWORK CONFIG. Dante/AES67 ROUTING

PANEL FUNCTIONS

TECHNICAL DATA

## 4. DESCRIPTION & FEATURES

**BOB-22** is a digital audio interface, 2xMIC/LINE audio inputs and 2 LINE level audio outputs, Dante/AES67 (Audio Over IP) Break Out Box. It enables the conversion of up to 2 Dante/AES67 channels into 2 analogue audio LINE level output signals and vice versa, converting 2 MIC/LINE analogue audio input signals into 2 Dante/AES67 channels for transmission over an Ethernet network.

The device features PoE (Power over Ethernet) for DC power directly from PoE-enabled Ethernet switches. An optional 24VDC external PSU is available (sold separately).

BOB-22 is a generic Dante/AES67 device that can be used in combination with EclerNet / EclerPLEX / VIDA / HALO Dante devices from Ecler, or with any other third-party Dante/AES67 devices, but it is not a native EclerNet / EclerPLEX guest unit.

### 4.1 Main Features

- Ethernet interface.
- Euroblock connectors for analogue audio inputs and outputs.
- 2 Analogue MIC/LINE audio inputs reception.
- 2 Analogue LINE level audio outputs.
- 2x2 Digital audio -transmission and reception -channels in Dante/AES67 format.
- PoE power supply ready.
- Compact format.
- Frontal support Half rack accessory included.

## 5. INSTALL & CONNECT

### 5.1 Installation


BOB-22 has been especially designed to be installed in a standard 19" rack, taking up 1U (height) and only half the width. It includes a half rack adapter which allows two rack width media devices to be mounted on racks of 1 standard unit of measure (19"). Please refer below for the assembly instructions.

**!** Since the device features a heat generator, it should not be enclosed or exposed to extreme temperatures.

**!** If multiple units are installed in the same rack or in a cabinet with closed doors, it is highly recommended to install fans in their upper and lower ends for a forced air flow from the bottom up. This upward air flow will favour the dissipation of heat generated inside.

#### 5.1.1 Half Rack Adapter Assembly

BOB-22 includes a half rack front adapter which allows two rack width media devices to be mounted on racks of 1 standard unit of measure (19").



PRECAUTIONS

WARRANTY  
&  
ENVIRONMENT

PACKAGE  
CONTENTS

DESCRIPTION  
&  
FEATURES

INSTALL  
&  
CONNECT

START-UP  
&  
OPERATION

NETWORK CONFIG.  
&  
Dante/AES67 ROUTING

PANEL  
FUNCTIONS

TECHNICAL  
DATA

## 5.2 Connections


### 5.2.1 Audio input connections

BOB-22 rear panel provides 2 balanced analogue signal inputs , supporting Line or Mic levels and Phantom Power ready.



Signal input connectors are 3 position screw terminal block. The wiring is:


Live or direct signal	>	Pin	+
Cold or inverted signal	>	Pin	-
Ground	>	Pin	⊥



**!** For unbalanced connection short-circuit pin ⊥ to pin - as reported on the picture.

**Microphone signal:** 2 channels offer a Euroblock connector for a nominal input level from -50dBV to 0dBV, with a GAIN control on the rear panel to adjust the gain.

**Wiring diagram for microphones:**



**!** Microphones must be low impedance (200 to 600 Ω) and monophonic.



PRECAUTIONS

WARRANTY  
&  
ENVIRONMENT

PACKAGE  
CONTENTS

DESCRIPTION  
&  
FEATURES

INSTALL  
&  
CONNECT

START-UP  
&  
OPERATION


NETWORK CONFIG.  
&  
Dante/AES67 ROUTING

PANEL  
FUNCTIONS


TECHNICAL  
DATA



Each analogue input has its own gain control knob.




BOB-22 supplies phantom power for condenser microphones, individually switchable by internal jumper.



By default, phantom power is disabled (factory setting).


## 5.2.2 Audio output connections

BOB-22 rear panel provides 2 analogue outputs for line-level signals.



Signal output connectors are 3 position screw terminal block. The wiring is:


Live or direct signal	>	Pin	+
Cold or inverted signal	>	Pin	-
Ground	>	Pin	⊥



For unbalanced connection short-circuit pin ⊥ to pin - as reported on the picture.

## 5.2.3 Ethernet / Dante/AES67 port

The RJ-45-type ETHERNET connector on the rear panel, allows the device to be connected to an Ethernet network.



BOB-22 allows transmission and reception of 2x2 Dante/AES67 channels.


For further information on Network Configuration and Dante routing, please [refer to the chapter Network Configuration and Dante/AES67 Routing](#).

## 6. START-UP & OPERATION

If PoE DC power is unavailable from the Ethernet switch, please connect the optional external PSU (sold separately) to the DC IN connector on the rear panel.



To avoid buzzing, do not allow the power cable to intertwine with audio shielded cables.



The device will automatically switch on and the ON led of the front panel will light up green.



PRECAUTIONS

WARRANTY  
&  
ENVIRONMENT

PACKAGE  
CONTENTS

DESCRIPTION  
&  
FEATURES

INSTALL  
&  
CONNECT

START-UP  
&  
OPERATION

NETWORK CONFIG.  
Dante/AES67 ROUTING


PANEL  
FUNCTIONS

TECHNICAL  
DATA


## 7. NETWORK CONFIGURATION AND DANTE/AES67 ROUTING

The routing of the digital audio signals Dante/ AES67 through the Ethernet network, as well as the network configuration of the ports Dante/ AES67 (IP addresses, mask, etc.) is managed by the software application Dante Controller.

 For further information, please refer to the developer's documentation: [www.audinate.com](http://www.audinate.com)

 **AES67 is enabled by default.** Dante devices cannot subscribe to AES67 streams from other Dante devices.

The device comes from factory with DHCP service activated. Therefore, the unit will automatically take a dynamic IP address served by a DHCP server in the local area network where it is connected to, in case it exists. However, specific static network parameters can be configured using Dante Controller, accessing to the window shown in this example:



PRECAUTIONS

WARRANTY  
&  
ENVIRONMENT

PACKAGE  
CONTENTS

DESCRIPTION  
&  
FEATURES

INSTALL  
&  
CONNECT


START-UP  
&  
OPERATION

NETWORK CONFIG.  
&  
DANTE/AES67 ROUTING


PANEL  
FUNCTIONS

TECHNICAL  
DATA

The default unit name, displayed as a label in Dante Controller, is factory-set to BOB-22-nnnnnnnn, where ‘nnnnnnnn’ matches the last 6 digits of the MAC address of each device. However, this name can be renamed through following window:




The routing for Dante/AES67 channel transmitters and receivers can be defined in the routing window, where all the devices with Dante capabilities detected in the network will also appear:



## 8. PANEL FUNCTIONS

### 8.1 Front Panel



1. **ON, POWER On** led indicator. Lights up when the unit is on.
2. **Dante/AES67LED** indicator:
  - **Red fixed LED** : during the boot up process.
  - **Amber fixed LED**: during the PTP (Precision Time Protocol) network time synchronization.
  - **Green fixed LED**: the unit has been set up as a Dante/AES67 Slave.
  - **Green blinked LED**: the unit has been set up as a Dante/AES67 Master.
3. **OUTPUTS Clip/signal** indicators x2
  - **Green LED**: SP
  - **Red LED**: Clip
4. **INPUTS Clip/signal** indicators x2
  - **Green LED**: SP
  - **Red LED**: Clip



PRECAUTIONS

WARRANTY  
&  
ENVIRONMENT

PACKAGE  
CONTENTS

DESCRIPTION  
&  
FEATURES

INSTALL  
&  
CONNECT


START-UP  
&  
OPERATION

NETWORK CONFIG.  
&  
Dante/AES67 ROUTING

PANEL  
FUNCTIONS

TECHNICAL  
DATA

## 8.2 Rear Panel



1. DC IN socket 24V.
2. Ethernet/Dante RJ-45 connector.
3. OUTPUT Euroblock connectors x 2
4. INPUT GAIN knob x 2
5. INPUT Euroblock connectors x 2



PRECAUTIONS

WARRANTY  
&  
ENVIRONMENT

PACKAGE  
CONTENTS

DESCRIPTION  
&  
FEATURES

INSTALL  
&  
CONNECT

START-UP  
&  
OPERATION

NETWORK CONFIG.  
&  
Dante/AES67 ROUTING

PANEL  
FUNCTIONS

TECHNICAL  
DATA

## 9. TECHNICAL DATA

### 9.1 Technical Specifications

#### BOB-22

Audio Converters	
Sampling rate	48 kHz
Resolution	24 bit
Latency	ADC 0.81 ms   DAC 0.56 ms   Total 1.37 ms
Frequency response	0 - 20 kHz
Dynamic range	ADC:110dB, DAC:115dB
Analogue Audio Input Ports	
Number of input ports	2, MIC/LINE level
Connection type	Euroblock, 3-pin, balanced
Input sensitivity	-50dBV to +0dBV
Input impedanc	> 4 kΩ
Max input level	+18dBV = +20dBu
THD + Noise	THD+Noise @ 1kHz, 0dBV input (line) <0.005% THD+Noise @ 1kHz, -40dBV input (mic.) <0.40%
CMRR	56dB typ.
Phantom power	+48VDC, Internal jumper activation
Analogue Audio Output Ports	
Number of output ports	2, LINE level
Connection type	Euroblock, 3-pin, balanced
Max output level	+18dBV = +20dBu
Output impedance	316 ohms
Crosstalk	better than 95 dB
Audio Over Ip	
Protocols	Dante® / AES67 (2/2 flows)
Number of digital input ports	2
Number of digital output ports	2
Interfaces	1 x RJ-45
Connectivity	
Ethernet	1, RJ-45 connector 10 /100Mb, 1GB Auto X-Over
Programming and control	Dante® Controller
Electrical	
Power supply	24VDC External PSU (sold separately)
Secondary power supply	PoE: class 0 802.3af Poe PD compliant
AC mains requirement	90-265VAC @ 50-60Hz (External PSU: 24VDC)
Power consumption	14 VA / 8 W
Ventilation	Passive
Physical	
Operating temperature	Min: -10°C ; 14°F Max: 40°C ; 104°F
Operating humidity	<85% HR
Storage temperature	Min: -10°C ; 14°F Max: 40°C ; 104°F
Storage humidity	<90% HR
Installation options	Desktop, 19" racks (1RU)



PRECAUTIONS

WARRANTY  
&  
ENVIRONMENT

PACKAGE  
CONTENTS

DESCRIPTION  
&  
FEATURES

INSTALL  
&  
CONNECT

START-UP  
&  
OPERATION

NETWORK CONFIG.  
&  
Dante/AES67 ROUTING

PANEL  
FUNCTIONS

TECHNICAL  
DATA




Included accessories	4x Euroblock 3-pin connectors, 4x Rubber feet, 1x Frontal Support Half-Rack accessory, 4x Washer.
Dimensions (WxHxD)	266.1 x 32 x 156.2mm / 10.48 x 1.26 x 6.15 in.
Weight	1.1 Kg / 2.43 lb.
Shipping dimensions (WxHxD)	430 x 52 x 261 mm / 16.93 x 2.05 x 10.28 in.
Shipping weight	1.7 Kg / 3.75 lb.

## 9.2 Mechanical Diagram

All measurements are in mm.



Ecler BOB-22 Mechanical Diagram



61-1125-0100

www.ecler.com

All the measurements are in mm



PRECAUTIONS

WARRANTY  
&  
ENVIRONMENT

PACKAGE  
CONTENTS

DESCRIPTION  
&  
FEATURES

INSTALL  
&  
CONNECT

START-UP  
&  
OPERATION

NETWORK CONFIG.  
Dante/AES67 ROUTING

PANEL  
FUNCTIONS

TECHNICAL  
DATA


PRECAUTIONS
WARRANTY & ENVIRONMENT
PACKAGE CONTENTS
DESCRIPTION & FEATURES
INSTALL & CONNECT
START-UP & OPERATION
NETWORK CONFIG. Dante/AES67 ROUTING
PANEL FUNCTIONS
TECHNICAL DATA



All product characteristics are subject to variation due to production tolerances. **NEEC AUDIO BARCELONA S.L.** reserves the right to make changes or improvements in the design or manufacturing that may affect these product specifications.

For technical queries contact your supplier, distributor or complete the contact form on our website, in [Support / Technical requests](#).

Motors, 166-168 | 08038 Barcelona, Spain | Tel. (+34) 932238403 | [information@ecler.com](mailto:information@ecler.com) | [www.ecler.com](http://www.ecler.com)