

1. Plug in CORE transmitter

Connect the transmitter DC adapter to the electrical outlet and use one of the 3 available audio inputs to connect the music source

2. Hangs GLOBE from the ceiling

AC CABLE

SUSPENSION HOLES FOR SECURITY CABLE

3. Power ON GLOBE

Check whether the unit is really powered or not by watching the LED indicators.
If blue and green LEDs start blinking the unit is ready to pair

4. Pair the devices

Make a short press on the WiS PAIR key (using a clip e.g.), the WiS and RX LEDs will start to blink

When the CORE and GLOBE lights stop blinking, the devices are paired

5. Select the input and play the music!

1. Press the SELECT key on the CORE transmitter.

2. Use a smartphone to play music.

3. The GLOBE will play the music.

WiSpeak grip

Use WiSpeak grip app for set up and control functions

